

Centrifuge Tubes

10 to 15ml Capacities

Reference Code:

C = Corning
E = Elkay
S = Scilabware
St = Sterilin

Materials Code:

Bs = Pyrex borosilicate glass
MPs = Modified polystyrene
PET = Polyethylene terephthalate
Pp = Polypropylene
Ps = Polystyrene
SI = Soda-lime glass

Caps Code:

F = Flat top rim seal type
P = Plug seal type
S = Screw type
W = Write-on panel

All tubes have rim unless otherwise specified. Graduations are moulded-in, unless otherwise specified.

Cat. No.	Capacity	Material	Shape	RCF (xg)	Grad.	L x dia. (mm)	Cap	Sterile	Ref.	Qty.
CF320-24	10ml	Bs	Straight rimless	3000	—	90 x 16	—	—	B (1660/02)	Each
CF320-26	12ml	Bs	Conical	3000	—	110 x 17	—	—	B (1680/02)	Each
TE604-65	13.5ml	Ps	Straight	8000	—	100 x 16	S	✓	St (142AS)	450
TE604-70	13.5ml	Ps	Conical	8000	—	100 x 16	S	✓	St (144AS)	450
CF326-14	15ml	PET	Conical	3600	✓	122 x 23	P	✓	C (430055)	500*
CF326-15	15ml	PET	Conical	3600	✓	122 x 23	P	✓	C (430053)	500
CF326-18	15ml	Ps	Conical	1800	✓	120 x 18	—	—	E (150)	1000
CF326-19	15ml	Pp	Conical	12500	✓	122 x 23	FW	✓	C (430790)	500*
CF326-20	15ml	Pp	Conical	12000	✓	122 x 23	P	✓	C (430052)	500*
CF326-22	15ml	Pp	Conical	6250	✓	118 x 17	—	—	E (151)	1000
CF326-26	15ml	Ps	Conical	1800	✓	118 x 17	S	—	E (2087)	1000
CF326-30	15ml	Pp	Conical	6250	✓	118 x 17	S	—	E (2088)	1000
CF326-38	15ml	Pp	Conical	6250	✓	118 x 17	S	✓	E (2098)	500*
CF328-21	15ml	Pp	Conical	8400	✓ (printed)	120 x 16	F, S	✓	—	500
CF328-22	15ml	Pp	Conical	8965	✓ (printed)	120 x 17	F, S	✓	—	500
CF328-25	15ml	Pp	Conical	6000	✓ (printed)	120 x 17	F, S	—	—	500
CF330-10	15ml	SI	Straight	1300	—	111 x 17	—	—	—	Each
CF330-22	15ml	SI	Conical	1300	—	111 x 17	—	—	—	Each
CF330-26	15ml	SI	Conical	1300	✓	111 x 17	—	—	—	Each
CF330-40	15ml	Bs	Conical	3000	✓	110 x 17	—	—	S (3460/02)	Each

*Supplied in racks of 50 within the outer pack quantity.

SAFETY NOTE

Relative centrifugal force (RCF) figures stated are maxima in ideal environmental conditions. The mechanical strength of tube materials can vary with exposure to certain reagents or with temperature changes. Care should be taken when using tubes at or near their operating limit.

